

Configuring the IBM Flex System EN2092 1Gb Ethernet Scalable Switch

Prerequisites:

- One IBM Flex System Enterprise Chassis, one IBM Flex System EN2092 1Gb Ethernet Scalable Switch installed in I/O module bay 1 or 2.
- An Ethernet network is already configured.

Steps:

Note: This process illustrates how to enable the switch ports through the Chassis Management Module (CMM) command-line interface. For information about using the CMM interface, you can use the “Configuring IBM Flex System Enterprise Chassis components” quick start guide. You can find that quick start guide at this location:

In the information center (Internet):

http://pic.dhe.ibm.com/infocenter/flexsys/information/topic/com.ibm.acc.commontasks.doc/commontasks_chassis_config.html

The IBM Flex System product documentation is also available on the IBM Flex System Manager management node. To access the installed documentation, click Information Center from the IBM Flex System Manager Home page and then navigate to: IBM Flex System information -> Quick start guides -> Installing and configuring the IBM Flex System Enterprise Chassis

1. Log on to the Chassis Management Module (CMM) CLI with an SSH application. The default IP address is 192.168.70.100 and the default login/password is USERID/PASSWORD. If necessary, obtain the IP address and login of the CMM from your system administrator.
2. Set the environment to the bay where you installed the switch. The following example is for bay 2:
`env -T system:switch[2]`
3. Run the following command to enable external data ports:
`ifconfig -ep enabled`

External ports 1 – 10 are now enabled for data throughput.

Activating additional keys:

If you have purchased additional keys, they need to be installed on the switch. Complete the following steps to install additional keys using the ISCLI interface.

1. To retrieve the key, navigate a browser to <https://www.ibm.com/systems/x/fod/index.wss> and sign in with your ID and password
2. Click **Request activation key**.
3. Enter the authorization code. The authorization code was supplied to you by email or on paper as part of the ordering process.
4. Click **Continue** and follow the instructions and download the key file.
5. Log on to the EN2092 switch with an SSH application. The default IP addresses for the switch through the CMM are as follows: 192.168.70.120 (bay 1), 192.168.70.121 (bay 2), 192.168.70.122 (bay 3), and 192.168.70.123 (bay 4). If necessary, obtain the IP address and login of the switch from your system administrator.
6. Enter **ena**.
7. Enter **software-key**.
8. Enter **ena**key address <hostname or IP address> keyfile <file name>
protocol tftp mgt-port

Note: you must reset the switch to apply the key.

9. Reset the switch. Enter **reload**.

Repeat the step for additional keys if needed. The sequence of steps is shown here:

```
Router#ena
```

```
Router(config)#software-key
```

```
Router(Software-Key)#enakey address 9.44.143.206 keyfile
```

```
ibm_fod_0007_Y010CM28N001_anyos_noarch.key protocol tftp mgt-port
```

```
Starting download key file...
```

```
Key file download complete (494 bytes)
```

```
Software feature 'Upgradel' will be Active upon next reboot.
```

```
Aug 5 11:47:39 1080:0:0:0:0:0:0:82 NOTICE mgmt: Software feature 'Upgradel'  
will be Active upon next reboot.
```

```
A Reboot is required for the new settings to take effect.
```

```
Router(Software-Key)#reload
```

```
...
```

```
Resetting at 11:47:59 Tue Aug 5, 2014...
```